

Unicycle.com

Using Pedal Wrench

Pedals coming loose is the prime reason for cranks stripping. If your pedals come loose regularly then it is more than likely that you have your wheel in the frame the wrong way around. Pedals should be tightened very tight and we recommend using a pedal wrench or good quality cycle tool

You will require:

- Pedal wrench or cycle wrench

Instructions:

1. Identify the pedal and crank are both for the same side. They both have on them markings to indicate if they are for the left or right side. This is because the threads go different directions.
2. Place some grease or lubricant on to the threads (new cranks normally have this on already)
3. Screw the pedals in as far as you can by hand.
4. Using the open end of the pedal wrench tighten the pedal hard against the crank. There should be no gap showing when it is seated.



Note:

Cranks stripping is not covered by the unicycle warranty. It is your responsibility to make sure the pedals are tightened fully and the wheel is installed correctly.