



You are going to need a 6mm Allen key, 13mm wrench and 15mm wrench. Your Mini Bike comes in kit form and should only take 5 minutes to assemble.

How to build your Mini Bike

- A. Straighten the handle bars and tighten the 6mm allen key bolt located on the top of the stem.
- B. Fit the pedals onto their correct cranks by matching the letter on the cranks with those on the pedals. Tighten firmly using your 15mm spanner (the left hand crank has a reverse thread).
- C. Adjust the saddle height using a 13mm wrench.