



What should be in your box:

Mini Bike  
Pedals

You are going to need a 6mm allen key,  
13mm wrench and 15mm bicycle type  
wrench.

Your Mini Bike comes in kit form and should only take 5 minutes to assemble.

## How to build your Mini Bike

- Straighten the handlebar and tighten the 6mm allen key bolt located on the top of the stem.
- Fit the pedals onto their correct cranks by matching the letter on the cranks with those on the pedals. Tighten firmly using your 15mm bicycle type wrench (the left hand crank has a reverse thread).
- Adjust the saddle height using a 13mm wrench.
- Always wear safety gear when learning. Safety is your own responsibility.